To a Projector or monitor

■ PACKAGE CONTENTS □ AC adapter □ AC adapter ☐ AC adapter (For Japan/ (For Europe only) (For Asia only) North America only) ☐ Warranty Card (For Japan/North America only) ☐ IMPORTANT SAFEGUARDS Make sure to read the "IMPORTANT ☐ Quick Start Guide (this book) SAFEGUARDS" in this guide before

X Caution □ Note (For Europe only) using the product. ☐ USB Cable **PREPARATION** SETTING UP • Connect the AC adapter. Connect a display device such as a monitor. To a wall outlet (<u>@</u> Red light DC IN 5V HDMI OUT RGB OUT AC adapter HDMI cable AC adapter Convex About AC adapter Fit the convex part of the plug in the groove of the AC adapterand push it downward.

- Y Push it until you hear "click".
- * Choose the correct plug according to the outlet.

When removing the plug from the AC adapter, slide the lock button to the direction of ▼ and pull the plug upward. :.....

USING THE PRODUCT

1. Turn on the power.



2. The camera image appears.



Blue light

3. Place an object to be displayed under the camera.



4. Adjust zoom and focus.

Zoom

Enlarge



Shrink



Press


Press

Auto focus (focus adjustment)



Press

5. Turn off the power.



UVC(USB Video Class)

Connect to a computer, etc.



1.Connect the USBcable



- 2. Start the UVC application such as a personal computer.

Note

- The frame rate may be decreased depending on the computer used.
- If the bus-powered power supply capacity is insufficient, the operation of this unit may become unstable. In that case, and when outputting USB and HDMI/RGB simultaneously, use the AC adapter to supply power.

DETAILED USAGE OF THE PRODUCT

For detailed information about the Instruction Manual, refer to the following website:

https://www.elmousa.com/

https://www.elmoeurope.com/index.php/en/

